

MODEL NO : ABS160A

MITSUBISHI LANCER EVOLUTION 8

PLEASE READ THESE INSTRUCTION CAREFULLY PRIOR TO INSTALLATION

Important Note: Please inspect your spoiler for proper fit before painting or mounting

Spoiler Installation

Drill Application STEP-by-STEP

Hardware Kit

Supplied on each spoiler

- | | | |
|----------------------------|------------------|--------------------------------|
| 1. Set of screws & washers | 3. Set of gasket | 5. Set of chromed steel plates |
| 2. Set of locator strips | 4. Allen key | |

Step 1

Tighten the chromed steel plates on both ends of the spoiler (see illustration 1)

Step 2

Tighten both the spoilers' legs to the chromed steel plates (see illustration 2)

Step 3

Tighten both the legs' cover (see illustration 3)

Step 4

Insert the locator strips into the mounting holes. A small piece of masking tape will hold it temporarily in place (see illustration 4)

Step 5

Set the spoiler in the position you feel looks best

Step 6

Tape the locating strips to the trunk lid on both sides of the legs. Carefully lift the spoiler off the trunk lid leaving the locating strips (see illustration 5)

Step 7

Drill through the centre of the locating strips (see illustration 6)

Step 8

Apply the gaskets to the bottom of the spoiler to avoid paint scratches

Step 9

Tighten the screws through the gasket and into the holes of the spoiler. Only tighten them to a snug position (see illustration 7)

Step 10

Finish tightening all the screws to hold the spoiler securely to the trunk (see illustration 8)

ILLUSTRATIONS

