

PART NO : ABSWL-01 & ABSWL-02
MUSTANG WINDOW LOUVERS '05-09' & '10-13'

This Mustang Window Louvers are manufactured using virgin ABS resins

Installation Instructions :-

1. Clean the mounting areas using isopropyl alcohol or equivalent
2. Peel the double side tape backing at the corners (pls refer the photo)
3. Place the window louver on the correct position and peel the tape backing completely
4. Press the window louver gently onto the glass panel
5. Peel the black sticker backing and use the sticker for the internal surface of the glass panel

