

Painting Instructions for Fender Flares:-

1. Test fit the flares before commencing painting. (Clean hands without oil or grease; if not wash the flares with soapy water & allow the flares to dry 100%)
2. Spray 2 layers of flexible 2K Primer (preferably grey color)
3. Allow the primer to dry; wet sanding the flares with 600 or 800 grit paper.
4. Wipe the wet flares with clean new towel.
5. Allow the flare to dry 100% before applying color coat.
6. Allow the color coat to dry 100% then apply the clear coat.
7. Light buffing to shine the flares.